

Model JP

Jockey Fire Pump Controllers

Standard Features

1. Manual control
2. NEMA 2 enclosure
3. Locked motor overcurrent protection device
4. Alarm signal on pump controller
 - Pump running
 - Pump failure
 - Pump Trip



JP SERIES

DOL (Direct On-Line) Starter
Y/D Star Delta starter

Voltage	kW	Dimensions in mm
380V	1 - 7.5	500 x 400 x 220
	5.5 - 22	600 x 400 x 220

HOW TO ORDER : JP - V / kW / Ph / Hz
JP - 380 / 5.5 / 3 / 50



PT. SELARAS PELITA PERKASA

Head office

PT. SELARAS PELITA PERKASA

Ruko PalmCrown Blok OO1 No. 51
Jl. Taman Surya 5 Pegadungan
Kalideres, Jakarta Barat, Indonesia 11830

Workshop & Warehouse

Jl. Hasyim Ashari, Kavling DPR
Blok A No. 240-243
Kenaga – Cipondoh, Tangerang

Sales & Inguiry

Office Phone : +62 21 5433 8985
Mobile : +62 812 1990 8400
Email : sppindo.sales@gmail.com